

Step1,安装 Raspbian 官方镜像

- (1)从官方下载最新 Raspbian 镜像
- (2)使用 SDFormatter 格式化 Micro SD 卡
- (3)使用 Win32DiskImager 把官方镜像烧录到 Micro SD 卡

Step2,与树莓派连接



插入 Micro SD 卡，连接网线，接好电源



扫码获取

更详细 WIKI 资料

Step3,安装树莓派驱动

- (1) 登陆树莓派终端 (SSH 远程登录用户名: pi 密码: raspberry)
- (2) 执行以下命令 (树莓派需连接互联网):

```
sudo rm -rf LCD-show
git clone https://github.com/goodtft/LCD-show.git
chmod -R 755 LCD-show
cd LCD-show/
sudo ./MHS40-show
```

- (3) 执行完上述命令后，系统自动重启后就能正常显示和触摸了

MHS-4.0inch Display-B Quick Start

www.lcdwiki.com

Step1, Install the Raspbian official mirror

- (1) Download the latest Raspbian mirror from official
- (2) Use <SDFormatter> to format Micro SD card
- (3) Use <Win32DiskImager> to burn the official image to Micro SD card

Step2, Connect with Raspberry Pi



Align right-side to insert the LCD screen

Plug-in Micro SD card, connect network and power

Scan the QR Code

For more details

Step3, Install Driver for Raspberry Pi

- (1) Login to Raspberry Pi terminal by SSH (User name: pi, Password: raspberry)
- (2) Execute the following commands (Raspberry Pi needs to connect Internet):

```
sudo rm -rf LCD-show
git clone https://github.com/goodtft/LCD-show.git
chmod -R 755 LCD-show
cd LCD-show/
sudo ./MHS40-show
```

- (3) After the above commands are executed, the system will automatically restart and be able to display and touch normally now.